



MFS-B3

User manual

Marvel Electrical scooter

Enjoy, ride and get home safely.



Electric scooter details



Appearance of electric scooter



Folding Icon



Unfold Icon

Warning and safety

Warning!

The responsibility for the repair and maintenance of the electric scooter is assigned to you, which can help you reduce the danger and injury. Reading this manual and following it will help you reduce the risk.

Be careful:

- ① : be sure to comply with local traffic laws and regulations.
- ② : no riding in low visibility.
- ③ Don't use the car for stunts, wheels, or jumping movements, which will increase your chances of injury and damage to the car.
- ④ : no passengers.
- ⑤ : make sure the safety catch and screws are locked and fastened before riding.

Safety instructions!

1. This product can only be used by one person. Do not carry others at the same time.
2. When riding this product, please wear a safety helmet. When riding, please hold the joystick with both hands correctly. It is forbidden to ride with one hand.
3. It is recommended to charge continuously for 6 hours before the first use to maintain the best condition.
4. Please contact in the open area now, and drive after being familiar with the operation of this product.
5. Do not ride this product on unsafe or illegal roads.
6. Do not turn off the power supply while the vehicle is moving.
7. Do not use this product in an environment lower than - 5 °C. Please charge the lithium battery at least once every 30 days when it is not in use.
8. Keep your feet on the car when it's moving.
9. Slow down and drive carefully when passing rough roads.
10. Do not ride on the ground with water, oil or ice on the surface.
11. Do not allow the product to be placed in a water depth of more than 5cm or directly impacted by water, which will cause motor and circuit faults

Tips:

When you want to accelerate, lean forward. When you brake, lean back!

Operation guide

Battery

Do not operate the motor while charging!

The indicator light on the accelerator shows the power only roughly (full / empty)!

Do not store the battery fully charged for a long time (more than two months)!

Do not use the battery if:

- 1: When damaged
- 2: When abnormal smell and heat are released
- 3: When any leakage occurs

Avoid contact with substances leaked from the battery

Batteries should be kept out of the reach of children and pets

Exposure to battery voltage can cause death or injury

Using, storing and charging the electric scooter outside the specified scope will lead to the invalidation of warranty period, battery damage and battery charging invalidity.

General troubleshooting

When the product cannot operate normally, please check whether the following actions have been completed:

1. Power on
2. The power display shows the remaining power
3. The brake has been released
4. All sockets and connectors are clean and connected accurately

If the above actions are completed and the single product still cannot operate normally, please consult the product dealer!!

Power switch

Electric quantity

Speed

Function Key

LCD Screen

Mileage

Key



Product parameters

Product name:	MFS-B3
Boundary dimension:	136*53*106cm
Motor power:	350W
Battery capacity:	36V 10AH
Motor type:	DC brushless motor
Tire size:	12 inch pneumatic tyre
Maximum load:	120KG
Battery type:	lithium battery
Vehicle weight:	27KG
Charging time:	3~4H
Brake type:	Front and rear disc brake
Maximum speed:	30KM/H
Maximum mileage:	30-40KM(The load, speed and road conditions during riding will affect the battery life)